



Mincey Marble Mfg., Inc.

4321 Browns Bridge Road
Gainesville, GA 30504

Ph: 800.533.1806

Fx: 770.531.0935

www.minceymarble.com

Installation Instructions for Mincey Marble Manufacturing's

4 x 12 Accessories Shelf

Product number #AS- 01



AS-01

Please read the following before attempting to install your new cast marble wall mounted Integral Support Shelf.

These instructions have been written for Mincey Marble's AS-01- 4" x12" cast marble Accessories Shelf. If you have received a product other than what's shown, please call our office so we can send the correct instructions to you.



Materials/Tools required:

1. Hot melt glue gun and hot melt glue sticks. * See note below for recommended hot melt glue sticks.
2. 100% Silicone for use as adhesive to install shelf.
3. Torpedo level
4. Measuring tape
5. Pencil
6. Color matching 100% Silicone for caulking the perimeter of the shelf once it has been installed.
7. Acetone to clean both the wall and the back of the shelf.
8. Clean, dry rags for cleaning wall and back of shelf.

If installing the Accessories Shelf on a tub or shower surround panel, you will need to have completed the installation of the surrounds and cleaned the area where the self is to be placed with acetone BEFORE the accessories shelf is to be installed.

Installing the 4 x 12 Accessories Shelf:

1. Locate plans and determine exact placement of shelf. This shelf is usually installed above the shower valve, when installed in a door-less walk-in shower.
2. The larger 4 x 12 side will be the top of the shelf when installed. The smaller 3 3/8" side will be the side that is adhered to the shower panel.
3. Using the torpedo level and pencil, level the shelf, centering the shelf on the wall in the desired location and mark the wall so that when the adhesive is applied, you will be able to set the shelf level.
4. Apply Silicone to the back of the shelf support, using circular glue pads.
5. Using the hot melt glue gun, apply a small amount of hot melt glue onto the back of the shelf support. You will need to act quickly when setting the shelf, as the hot melt glue will dry very fast. Set the shelf in the desired position, already marked on the wall with the pencil.
6. The hot melt glue will hold the shelf in place long enough for the silicone adhesive to cure. **DO NOT USE HOT MELT GLUE ALONE TO ADHERE THE SHELF.**
7. Once the shelf has been installed, before the silicone has cured, check again the level of the top of the shelf with the torpedo level. Minor adjustments may be made If this is checked before the hot melt glue has dried.
8. When satisfied with the position and level of the shelf, seal the seam where the shelf makes contact with the shower panel with a color matching 100% Silicone.

Mincey Marble Manufacturing recommends using a high temperature hot melt glue stick when attaching our cast marble shelf to our surrounds. The company we purchase our glue sticks from is AIM Supply and the part number is BO 6390-15. This is a ½" x 15" Adhesive Glue Stick. If your installer wants to use glue sticks from Home Depot or Lowe's, we recommend the Arrow Fastener's 4" Super Strong Glue Stick, however, these may not be available at all Lowe's or Home Depot store locations.

As a precaution - **DO NOT USE ALL PURPOSE GLUE STICKS**. They do not hold the weight of the shelf as well.

If you decide to purchase your glue sticks from AIM Supply you can contact them direct toll free at 800.999.0125 or on the web at www.aimsupply.com. They will accept orders 24/7, either on line or by phone.

If you have any questions, please call Mincey Marble Customer Service at 800.533.1806.